

G35 Coupe/Sedan Driver Side Battery Cover Installation Instructions

Tools required:

-Thin Flathead Screwdriver

Warning:

Please practice proper safety precautions when working on your automobile. CZP is not responsible for any injury or misuse of product.

This Kit Includes:

- *Driver Side Battery Cover (1)
- *Bracket (1)
- *Push-In Clips (5)



To Install:



1. Remove hole cover by carefully prying out with a flathead screwdriver.

5. Remove stock weather stripping.



2. Remove rivet cap from upper right hand corner of the compartment.



3. Place bracket so that the bracket's hole runs flush with the hole created from Step 2.



4. Replace rivet cap that was removed in Step 2 to secure bracket.



6.A. Place driver's side battery cover in place. Start with the top edge closest to the firewall.



6.B. Then place the bottom half of the cover to make a snug fit.



7.A. To secure the hole in the upper right portion, place a rivet clip through the hole and into the hole running flush from the bracket. Hold onto the bracket with your hand to secure it in place, while inserting the rivet cap.



7.B. This is what it should appear as.



8. Place a rivet cap to secure the hole in the lower right portion of the battery cover. This hole was created via Step 1.



9.A. Replace stock weather stripping starting from the bottom. Make sure that the stripping runs flush with the battery cover.



9.B. Then finish replacing the weather stripping at the top.